


Cojinetes

De roscar

Cojinete de roscar



A4 4001
STD



Tam. M1 - M 1,4 = Campo de tolerancia 6h.

MATERIAL	Paso mm	Ø exterior x Altura mm
M 1	0,25	16X5
M 1,2	0,25	16X5
M 1,4	0,30	16X5
M 1,6	0,35	16X5
M 1,7	0,35	16X5
M 2	0,40	16X5
M 3	0,50	20X5
M 3,5	0,60	20X5
M 4	0,70	20X5
M 5	0,80	20X7
M 6	1,00	20X7

MATERIAL	Paso mm	Ø exterior x Altura mm
M 7	1,00	25X9
M 8	1,25	25X9
M 10	1,50	30X11
M 12	1,75	38X14
M 14	2,00	38X14
M 16	2,00	45X18
M 18	2,50	45X18
M 20	2,50	45X18
M 24	3,00	55X22
M 30	3,50	65X25

Cojinete de roscar, para aceros inoxidables y altamente resistentes



A4 4005



Tolerancia 6g.

MATERIAL	Paso mm	Ø exterior x Altura mm
M 2	0,40	16X5
M 2,5	0,45	16X5
M 3	0,50	20X5
M 4	0,70	20X5
M 5	0,80	20X7
M 6	1,00	20X7

MATERIAL	Paso mm	Ø exterior x Altura mm
M 8	1,25	25X9
M 10	1,50	30X11
M 12	1,75	38X14
M 14	2,00	38X14
M 16	2,00	45X18
M 20	2,50	45X18

Juego de machos de roscar a mano y cojinetes Mf



A4 4003
STD

Métrica fina A4 403	Mf6-20
1 juego de machos de roscar manuales	6x0,75 / 8x0,75 / 10x1 / 12x1 / 12x1,5 / 14x1,25 / 14x1,5 / 16x1,5 x / 18x1,5 / 20x1,5
1 cojinete de roscar	6x0,75 / 8x0,75 / 10x1 / 12x1 / 12x1,5 / 14x1,25 / 14x1,5 / 16x1,5 / 18x1,5 / 20x1,5
1 volvedor giramachos ajustable	1 y 3
1 portacojinetes de roscar	20x7 / 25x9 / 30x11 / 38x10 / 45x14